

RELIABLE
STORMWATER
MANAGEMENT

HOMEOWNER GUIDE

V1.0

*storm***PANEL** 

YOUR STORMPANEL TANK

With the preservation of our precious environment becoming increasingly important, many people are now choosing to manage their stormwater in an environmentally sensible manner.

Well done on making the decision to partner with Devan to manage your stormwater.

What you need to know!

The stormPANEL tank structure is maintenance free but should be visually inspected during the course of routine maintenance. The overflow mechanism, silt trap and sludge build up in the tanks will require routine maintenance and the frequency of this maintenance will depend on the stormwater quality.

Annual Checks:

The following visual checks can be carried out from outside the tank with only lid removal, you are not required to enter the tank. Any entry for any reason in to the tank must only be completed by competent persons in line with WorkSafe requirements as the inside of the tank is a confined space.

- Lids for sealing against bug and vermin
- Silt build up
- Overflow for blockages
- Orifice outlets for blockages

Light blockages and build up:

Using a hose with a jet nozzle spray away the build up from the outlet orifice, use a wet and dry vacuum cleaner to remove excess water, sludge and silt built up

Heavy blockages and build up:

Use a contractor with an industrial vacuum to clean the tank and if required remove the leaf guard and physically clean orifice hole and leak guard.

INSTALLER TO COMPLETE:

INSTALL DATE:

INSTALLED BY:

SERIAL NUMBER:

VOLUME:

ORIFICE SIZE:



Tauranga Factory & Sales

PO Box 2602
125 Birch Avenue
Tauranga
Phone: 07 578 8726
Free Phone: 0800 338 268
Email: tauranga@devan.co.nz

Christchurch Factory & Sales

PO Box 16720
26 Columbia Avenue, Hornby
Christchurch
Phone: 03 421 7340
Free Phone: 0800 500 026
Email: christchurch@devan.co.nz

Buy online or find more information @ www.devan.co.nz